

# Accu-Zorb & Accu-Sep

## Pre-Adsorber & Media Bed Replacement Procedure



- 1) Remove media from plastic bags and thoroughly hose down the **pre-adsorber & media beds** (figure 1a) while rolling them (figure 1b) until water runs clear.
- 2) Shut off condensate flow to inlet diffuser assembly and remove the access lid.
- 3) Remove & discard **diffuser pad** from diffuser assembly (figure 3a). Remove four (4) screws holding holding diffuser assembly and set aside (figure 3b). Remove and discard **separation filter** from bottom of sediment chamber (figure 3c). Remove sediment chamber from unit. Rinse and empty chamber, then reinsert into unit.
- 4) Install new **separation filter** in the bottom of sediment chamber (figure 4a), followed by a new **diffuser pad** in the diffuser assembly (figure 4b). Reinstall the diffuser assembly to the vessel using the four (4) mounting screws (figure 4c).
- 5) Firmly grab **media bed** and slowly lift out of chamber (figure 5), and suspend over chamber for a couple minutes to allow bag to drain. Discard used media bed and pre-adsorption pad.
- 6) Install new **media bed** (figure 6a), and **pre-adsorption pad** (figure 6b). Finally reinstall access lid and turn on condensate flow to inlet diffuser assembly (figure 6c).



Figure 1a



Figure 1b



Figure 3a



Figure 3b



Figure 3c



Figure 4a



Figure 4b



Figure 4c



Figure 5



Figure 6a



Figure 6b



Figure 6c

**ATTENTION: PLEASE BE SURE TO COMPLY WITH ALL APPLICABLE REGULATIONS WHEN DISPOSING OF LUBRICANT CONTAMINATED FILTERS.**

**CONTACT YOUR LOCAL DISTRIBUTOR OR SERVICE PROVIDER FOR YOUR REPLACEMENT MEDIA KITS**